

Only measure the inside part of the window frame.

©ESTORES LOWCOST



## 3. Measure the width

To measure the width for the mosquito net, measure the width of one of the window cases.

