




CEILING MOUNTING




Install/ fix the box with the holders (ceiling or wall)

Define the position of the first holder (10 cm from the edge) and mark the spot of the hole. Make the hole with a drill and insert the bushing. Screw the first holder and slightly tighten the fixing screw.


Afterwards, place the second holder at the same distance from the other edge of the box.

If it is required a third holder, place it between the two other holders.

WALL MOUNTING



Fixed to the back of the box
SYSTEM "Clip"



Screw the fixing holders to the ceiling or to the wall as you wish and, subsequently, place the box in its position. This holder has a "clip" system that allows an easy removal.

In case of wall mounting, we advise the use of a level for more precision.

By using the chain (ascent and descent) you can control the transparency or no transparency.